



## CEREC Primemill

The CEREC Primemill is available for order as a configurable device.

Description	REF.
CEREC Primemill	66 17 570

## Scope of Delivery

**The following accessories are included with every CEREC Primemill delivery:**

- CEREC Primemill basic unit
- Water tank (in unit) with filter insert
- Adapter sleeve
- Removal tool for adapter sleeve
- Calibration set
- Torque wrench
- Torque wrench HT
- Pressure screws, 3x
- Starter Set Diamond CS
- Starter Set Bur CS
- Technical documentation
- Power cable
- Crossover cable (LAN) 10m
- Block clamp tool
- Dentatec 1000ml
- Water tank filter, separately packed
- Tank cap opener
- Cleaning set
- Sieve insert
- O-rings, 3x

**The following devices and components can be ordered as separately packed options:**

- Suction device, 230V or 120V, with power cable
- Set Cleaning Hose
- inLab PC with power cable
- LAN switch
- LAN cable, 2 m
- USB license drive
- Monitor with power cable

# Accessories

The CEREC Primemill uses the same suction device and accessories as the CEREC MC XL-family units. Furthermore, the top-loading filter is the same type as used with the CEREC MC X.

Description	REF.
Dust Collector CEREC MC 120 V (ordered together with CEREC Primemill)	65 69 748
Dust Collector CEREC 230 V (ordered together with CEREC Primemill)	65 69 730
Dust Collector CEREC (ordered separately)	65 80 786
Set Hand Cleaning Hose*	67 21 307
Filter bag 2-pack, CEREC	65 78 095
HEPA Filter	63 85 277
Dentatec, 1000 ml	58 09 640
Filter (1 piece)	63 87 067
Filter (6 pieces)	64 29 950

Additional accessories for the CEREC Primemill are listed below. Furthermore, a complete range of spare parts is available for order on our Spare Parts List.

Description	REF.
Tank cap opener	62 80 171
Interchangeable blade TX 10x132	67 11 340
Block Clamping Tools, spare part	67 18 410
Torque spanner HT, spare	64 79 856
Torque spanner, spare	64 79 849
Exchange sleeve	66 23 792
Extraction tool exchange sleeve	67 04 790
Calibration Kit, spare part	67 18 444
Calibration Pin (2x), spare part	67 32 528
Screw set, spare (5 pcs)	62 58 987
Cleaning Set, spare part	67 18 451
Sieve Insert, spare part	67 18 469
10-Base-T Crossover Cable 10 m	61 51 562

\* New accessory. This part fits on top of the suction device and has one hose connected to the milling unit and a second smaller flexible hose with nozzle which is used to easily vacuum out dust from the production chamber.



**Normal setting**

with handle switched to machine.



**Rotate the handle**

Rotate the black handle to the cleaning position. The suction device's switch changes from Auto to On which manually activates the suction for cleaning.



**Vacuum the chamber**

Easily vacuum out dust from the production chamber.